

## FERMACELL Jointstik

### For FERMACELL Gypsum Fibreboards

#### Application

To joint square edged FERMACELL Gypsum Fibreboard and Powerpanel H<sub>2</sub>O butted for walls and ceilings. Not suitable for subsequent filling/bonding of joints.

#### Properties

- Tested by the **Eco-Institute in Cologne**
- **Easy application**
  - Bonds and fills joints at the same time
  - Optimised application for walls and ceilings
- **Special applicator nozzle**
  - that dispenses the correct amount of adhesive right to the middle of the joint
- **High joint strength**
  - No joint gaps if applied correctly
  - Full board strength even on un-supported horizontal joints

#### Application

FERMACELL Jointstik is applied as a flat bead to the middle of the board's edge using the nozzle supplied with the cartridge. The special nozzle dispenses just the right amount of adhesive for a board thickness of 10 and 12.5 mm. The nozzle will need to be cut to the appropriate length for boards with a thickness of 15 and 18 mm. This increases the amount of adhesive applied. The second board is then butted tightly against the first one and fixed into position. The maximum joint width is 1 mm. At a room temperature of 15 to 25 °C the adhesive will be fully cured after 18 to 36 hours. Any excess adhesive must then be removed cleanly, e.g. with the FERMACELL Glue Scraper or a spatula. The areas of the joint and removed adhesive are then smoothed over with FERMACELL Joint Filler or FERMACELL Fine Surface Treatment. The temperature of the adhesive should be at least +10 °C. The material and room temperature must not be below +5 °C. The relevant installation instructions also apply. Further information: [FERMACELL Installation guide for walls and ceilings](#) (click here to download or go to [www.fermacell.co.uk](http://www.fermacell.co.uk)).



#### Material properties

Consumption	approx. 20 ml/metre run of joint (d=10/12.5 mm)
Material and room temp.	≥ +5 °C
Adhesive temperature	≥ +10 °C
Drying time	18 to 36 hours at 15 °C to 25 °C
Storage	12 months, cool and protected from frost*
Colour	Beige

\* FERMACELL Jointstik is not damaged by brief periods of frost during transportation and storage.



#### Distributor information

	Cartridge	Foil bag
Article number	79023	79029
EAN	4007548001687	4007548002042
Customs tariff no.	39095090	39095090
Quantity / Units	310 ml	580 ml
Quantity / Carton	25 cartridges	20 units
Quantity / Pallet	48 cartons	33 cartons
Weight / Pallet	approx. 740 kg	approx. 645 kg

#### Information on safety

Suitable protective gloves should be worn when applying the product. Take care not to allow skin, eyes, tools and clothing to come into contact with uncured FERMACELL Jointstik. Any areas of skin that have come into contact with the adhesive must be washed immediately with soap and water. Contaminated tools must be cleaned immediately with universal thinning agent. Once cured, the adhesive can only be removed by mechanical means.

Harmful to health: Keep out of reach of children! For further information on handling the product please read the label or the safety data sheet according to 1907/2006/EC article 31.

Emergency telephone number +49 551-19240

#### FERMACELL Customer Information:

Fon +49 203 501 90 40

Fax +49 203 501 90 80

E-mail: [Info@xella.com](mailto:Info@xella.com)

[www.xella.com](http://www.xella.com)

Revised 05/2009. We reserve the right to make technical changes. Note current application/installation instructions! Only the current version of this document is valid.

FERMACELL® is a registered trademark of the XELLA Group.